



LAMINATION ROLLERS

6. USING A STIFF PIECE OF CARD STOCK, FEED THE PHOTOPOLYMER THROUGH THE LAMINATION ROLLERS

5. WRAP LINER BACK AROUND TAKE-UP REEL AND TAPE IN PLACE.

RELEASE LINER TAKE-UP

4. LAY RELEASE LINER BACK OVER TOP OF PHOTOPOLYMER ROLL

ADAPTER IDLERS

RELEASE LINER

3. FEED PHOTOPOLYMER AROUND LOWER LAMINATOR IDLER AND PEEL OFF RELEASE LINER

LOWER LAMINATOR IDLER

2. THREAD PHOTOPOLYMER OVER LOWER ADAPTER IDLER

ADAPTER SUPPLY ROLL

1. MOUNT PHOTOPOLYMER INTO ADAPTER SO THAT THE FILM FEEDS TOWARDS THE BACK OFF OF THE BOTTOM OF THE ROLL. *MAKE SURE THAT THE LOWER ROLL LINES UP WITH THE FILM LOADED IN THE UPPER SUPPLY ROLL.*